

Pool Care Kit

Assembly Guide

PC2012-001



STEP 1

To vacuum your EZ Pool, locate the vinyl liner vacuum head and attach the blue end of the vacuum hose to the vacuum head. The blue end will swivel as you vacuum the floor.



STEP 2

Attach the blue metal “telescopic” pole to the vacuum head. This pole can be extended to as much as 8’ allowing you to move the vacuum head around the EZ Pool floor to clean and vacuum up debris on the floor.



STEP 3

In your pool care kit, you will find a tapered hose adapter. Attach this to the EZ Pool’s OUTLET from inside the pool. This would be the fitting without the Water Flow Directer.





STEP 4

Place the vinyl liner vacuum head on to the EZ Pool floor and submerge the entire vacuum hose. IMPORTANT: Get all the air out of the hose BEFORE attaching to the inside hose adapter. Then turn on your pump and filter and slowly move the vacuum across the floor.



STEP 5

After you finish vacuuming your EZ Pool floor, it would be best to remove your filter cartridge and clean it off. This is not necessary every time – it depends on how much dirt you vacuumed up.

2 WAY WATER TESTING KIT

The 2n1 Tester kit allows you to test the water for the two most important aspects: pH balance and chlorine levels. Typically for small residential pools this is all that is really needed to monitor your EZ Pool's water clarity.

